

Klebeanleitung Fallschutzplatten Adhesive instructions for impact protection












Benötigtes Material

- Klebekartusche für Fallschutzplatten (Art. E97003)
- Auspresspistole

Material

- Glue for impact protection system (Art. E97003)
- Cartridge applicator gun
- Der Kleber wird kreisförmig auf die hervorstehenden
 Quadrate und entlang der abgerundeten Kanten aufgetragen.
- Achtung: es müssen 3x Klebespuren auf die abgerundeten Kanten aufgetragen werden.
- The glue is laid on in circular form on the out-standing squares and along the rounded edge.
- Attention: there must be applied 3x thick traces of glue along the rounded edge.
- Fallschutzplatten bündig auf den Rahmen setzen und gut festklopfen.
- Place the impact protection tile flush on the frame and tap strongly.

Wichtige Verarbeitungshinweise / Important processing instructions:



 Haftflächen zuvor reinigen! (frei von Fett, Öl, Staub, Wasser, Klebstoffen...)

Clean surfaces before use! (free of grease, oil, dust, water, adhesives...)

Fertig! | Finished!

